

## WOODCLEANER

WOODCLEANER Ciranova® is a product for cleaning and degreasing exterior wood. WOODCLEANER can be used both on new wood and on wood that has already been treated. By using WOODCLEANER, you will achieve a smooth result when finishing the wood with a Ciranova® protection product.

- » Cleans and degreases the wood.
- » Ensures smooth end result after finish.
- » Easy to apply.



5L



PREPARATION



OUTDOOR



### PREPARATION

Pre-wet the wood for an optimal result of the product.

### APPLICATION

Apply WOODCLEANER with a brush. Scrub the wood with a soft scrubbing brush or use a buffing machine. Let the WOODCLEANER react and rinse the treated wood afterwards with water. Repeat this treatment if necessary.

### FINISHING

Finish with TEAKOIL, ECOPROTECTOR or DECKING OIL Ciranova®. Make sure the wood is completely dry before applying a protection layer.

## TECHNICAL DATA

### Cleaning

water

### Coverage

ca 10 m<sup>2</sup>/liter depending on the wood type

### Drying times

strongly dependant on the temperature

### Storage/transport

between 5°C and 25°C

### Disposal

dispose of residue and empty packaging in accordance with local ordinances.