

ECOPROTECTOR

Waterbased protection for the exterior wood. Especially adapted for the treatment of vertical surfaces. Is not film forming but penetrates into the wood. ECOPROTECTOR provides a nourishing protection that does not flake off.

- » Provides nourishing protection for exterior wood.
- » Does not flake off.
- » Ideal for treatment of vertical surfaces.



1L

2,5L



PROTECTION
OUTDOOR

PREPARATION

Make sure that all old finishing coats are completely removed. First clean the wood with WOODCLEANER or DEGREYER Ciranova®. After this preparation, slightly sand the surface so that Ecoprotector can easily penetrate.

APPLICATION

Stirr well before and during use. Apply the first layer with a brush in the direction of the wood fibres. Let dry for +/- 1 hour and apply a second layer. 2 or 3 layers are recommended depending on the wood types.

MAINTENANCE

Regularly maintain the wood with ECOPROTECTOR Ciranova®.

TECHNICAL DATA

Product type
waterborne

Cleaning
water

Viscosity
+/- 15 sec - DIN 4 mm

Coverage
+/- 15 m²/liter

Drying times
paintable after: +/- 1 hours
dust dry after: +/- 6 hours

Storage/transport
between 5°C and 25°C

Disposal
dispose of residue and empty packaging in accordance with local ordinances.